

REED A-SERIES MANUAL OVERRIDE MAIN CIRCUIT

- THE E-STOP CIRCUIT MUST BE RESET AND DUMP VALVES ENERGIZED.
- SWING PRESSURE IS REQUIRED TO MANUALLY OVERRIDE MAIN CIRCUIT
- MANUALLY DEPRESS OVERRIDE BUTTON "A" OR "B" TO SHIFT SWING TUBE AND STROKE MAIN CYLINDERS
- THE REVERSE VALVE ALSO HAS A MANUAL OVERRIDE BUTTON IN CASE OF ELECTRICAL FAILURE

