

electric control box 2 X 24 core BNC			
# 24 core BNC	# 24 core BNC	# 24 core BNC	
serial number	drawing mark	serial number	drawing mark
1	12.3	1	40
2	12.5	2	FQ
3	12.6	3	FT
4	12.7	4	45A
5	13.0	5	17
6	standby	6	18
7	13.2	7	31
8	13.3	8	33
9	Q2.3	9	34
10	12.0	10	37
11	12.1	11	38
12	Q2.7	12	10.1
13	Q3.0		
14	Q3.1		
15	Q3.2		
16	Q3.3		
17	Q3.4		
18	Q3.5		
19	Q3.6		
20	A12		
21	105C		
22	106C		
23	107C		
24	111C		
To Junction Box		To Receiver	

(2)	boom 1	DT26 DT27	11 12 40
(3)	boom 2	DT24 DT25	9 10 40
(4)	boom 3	DT22 DT23	7 8 40
(5)	boom 4	DT20 DT21	5 6 40
(1)	slewing magnetic valve	DT16 DT17	2 1 B4 B3 40
(7)	bypass valve	DT8	Q2.7 40
(6)	legging valve	DT11 DT12	Q3.2 Q3.3 40